


de	Montageanleitung
en	Mounting instructions
fr	Instructions de montage
sv	Monteringsinstruktion
nl	Montage-handleiding
it	Istruzioni di montaggio
fi	Asennusohje
es	Instrucciones de montaje
da	Monteringsvejledning
pl	Instrukcja montażu
cz	Montážní návod
hu	Szerelési útmutató
el	Οδηγίες εγκατάστασης
ru	Инструкция по установке
tr	Montaj talimatları
zh	安裝指導

Hilfsschalter
Auxiliary switch
Contact auxiliaire
Hjälpkontakt
Hulpschake-laar
Contatto ausiliario
Apukytkin
Contacto auxiliar
Hjælpe-kontakt
Przełącznik pomocniczy
Pomocný kontakt
Segédkap-csoló
Βοηθητικός διακόπτης
Вспомогательный выключатель
Yardımcı anahtar
辅助开关





				SKB62 SKC62 + ASC1.6 + ASZ62.6
--	--	--	--	--




SKB60, SKB62..., SKC60, SKC62...


SKD60, SKD62...



4





5




- de leicht anziehen
- en tighten slightly
- fr serrer sans forcer
- sv dra åt lätt
- nl licht aandraaien
- it fissare leggermente
- fi kiristää kevyesti
- es apretar suavemente
- da spændes let til
- pl dokręć lekko
- cz lehce utáhnout
- hu finoman meghúzni
- el σφίξτε με δύναμη
- tr hafifçe sıkın
- zh 轻微地锁紧




6




7



- de festziehen
- en tighten
- fr serrer à fond
- sv dra fast
- nl vastschroeven
- it fissare
- fi kiristää
- es atornillar
- da skruen fastgøres
- pl dokręć
- cz utáhněte
- hu erősen meghúzni
- el σφίξτε
- tr sıkın
- zh 锁紧





8



c1: ASC1.6

AC 24 V
10 mA ... 4 A resistive
max. 2 A inductive




10




de Montageanleitung
 en Mounting instructions
 fr Instructions de montage
 sv Monteringsinstruktion
 nl Montage-handleiding
 it Istruzioni di montaggio
 fi Asennusohje
 es Instrucciones de montaje
 da Monteringsvejledning
 pl Instrukcja montażu
 cz Montážní návod
 hu Szerelési útmutató
 el Οδηγίες εγκατάστασης
 ru Инструкция по установке
 tr Montaj talimatları
 zh 安裝指導

SKB60, SKB62...
 SKC60, SKC62...



74 319 0324 0

SKD60, SKD62...



74 319 0325 0

Issued by:
Siemens Switzerland Ltd.
Smart Infrastructure
Global Headquarters
Theilerstrasse 1a
CH-6300 Zug
Switzerland
+41 58-724 24 24
www.siemens.com/buildingtechnologies

© 1997 Siemens Switzerland Ltd
Technical specifications and availability subject to change without notice.