## **SIEMENS**

Document No. 129-232 September 29, 2009

# Diaphragm Replacement Kits for Powertop 658 and Flowrite<sup>™</sup> AP 599 Series 4-inch Pneumatic Valve Actuator

## **Product Description**

This kit contains replacement diaphragms for a Flowrite AP 599 or Powertop 658 Series 4-inch pneumatic valve actuator.

#### **Product Numbers**

Valve Type	Kit Number	Number of Diaphragms
Flowrite	599-01093	1
Powertop	658-166	5

### **Warning/Caution Notations**

WARNING	A	Personal injury/loss of life may occur if a procedure is not performed as specified.
CAUTION	A	Equipment damage, or loss of data may occur if the user does not follow procedure as specified.

## **Required Tools**

- 1/4-inch socket or open end wrench
- 5 mm hex wrench
- Flat-blade screwdriver

## **Prerequisites**

None

## **Expected Installation Time**

30 minutes to replace the actuator diaphragm.

#### Installation



#### **WARNING:**

The spring is under high compression. Make sure the valve stem is held securely in the stem retainer before removing the actuator upper housing.

#### Flowrite AP599 valve




Figure 1. Tighten the Valve Stem in the Stem Retainer.




Figure 2. Remove and Cap the Air Line. Remove the Actuator Upper Housing.

## Installation, Continued




Figure 3. Remove and Replace the Diaphragm.

Make sure the new diaphragm bead fits in the groove of the actuator lower housing.




Figure 4. Assemble the Actuator Upper Housing to the Lower Housing.

Follow the pattern shown in *Figure 4* for tightening the screws.




Figure 5. Tighten the Screws and Attach the Supply Air Tubing.

#### Installation, Continued

#### **Powertop VP658 valve**




Figure 6. Replacing the Diaphragm on a Powertop Actuator.

 Using flat-blade screwdriver, remove the six screws in the upper housing. Keep the screws and upper housing.

- 2. Remove and discard the old diaphragm.
- 3. Place the new diaphragm over the piston plate, and press the diaphragm bead into the groove of the lower housing.
- 4. Place the upper housing on the lower housing and fasten with the six screws.
- 5. Connect the air line.

The replacement is now complete.

#### References

**Technical Instructions** 

VP 658-4 Powertop Sequence and Sequence Changeover Valves 155-092P25

VP 658-5 Powertop Two-Way Flared Valves Normally Open/Normally Closed 155-310P25

AP 599-3 Flowrite<sup>™</sup> AP 599 Series 4-inch Pneumatic Valve Actuator 155-183P25

Information in this publication is based on current specifications. The company reserves the right to make changes in specifications and models as design improvements are introduced. Flowrite is a trademark of Siemens Industry, Inc. © 2009 Siemens Siemens Industry, Inc.