

- de** Montageanleitung
- en** Mounting instructions
- fr** Instructions de montage
- sv** Monteringsinstruktion
- nl** Montage-aanwijzing
- it** Istruzioni di montaggio
- fi** Asennusohje
- es** Instrucciones de montaje
- da** Monteringsvejledning
- tr** Montaj talimatları

QFM...

A

B

C

For US and Asia Pacific only:

<p>G AC 24 V ±20 % / DC 13,5...35 V</p> <p>G0 GND</p> <p>U... DC 0...10 V</p> <hr/> <p>I ... DC 4...20 mA</p> <p>G... DC 13,5...35 V</p> <hr/> <p>C + com</p> <p>C - com</p>	<p>B </p> <p>M </p> <hr/> <p>BS </p> <p>MS </p>
---	---

Open Source Software (OSS)

All open source software components used within the product (including their copyright holders and the license conditions) can be found from the website <https://www.siemens.com/download?A6V12393975>.

Issued by
Siemens Switzerland Ltd
Smart Infrastructure
Global Headquarters
Theilerstrasse 1a
CH-6300 Zug
Tel. +41 58 724 2424
www.siemens.com/buildingtechnologies

© Siemens Switzerland Ltd, 2004
Technical specifications and availability subject to change without notice.